

Video Search and Download Instructions For Speco NVR & DVR

Search & Playback

1. Right click on screen to show MENU.
2. Click on SEARCH.
3. Click on the return arrow icon to enter your password.
4. Enter password, then click ENTER, then click OK.
5. The search criteria screen will be shown.
6. Choose TIME LINE, click NEXT.
7. Click on the day from which you want to retrieve video, click NEXT.
8. Click and drag the red triangle to the selected starting time.
9. Choose either to display ALL cameras or specific channels.
10. Click PLAY. Recorded video is now playing.
11. Move cursor to bottom of screen to display control panel.
12. Click the X to stop video playback.

Download Still Image

1. Click on EXPORT button in control panel (second blue icon from right).
2. Choose STILL IMAGE to save or print a single image.
3. Click NEXT, choose USB DRIVE as the media type.
4. Insert USB drive into USB slot on front of unit.
5. Click START. This will save a copy of the still image which is currently displayed.
6. Click CLOSE once the download is complete.
7. Move cursor to bottom of screen and click X to stop playback.
8. Click CLOSE to return to live video.

View or Print Still Image

1. Insert USB drive into USB slot on laptop or desktop computer.
2. Open the USB folder to view files.
3. Double click on the file folder (name of folder will be the date downloaded).
4. Double click on the bitmap image file.
5. The still image will be displayed via your computer's photo app.

Download Video

1. Click on EXPORT button in control panel (second blue icon from right).
2. Choose NSF-PROPRIETARY FORMAT to save recorded video.
3. Click NEXT. Choose USB DRIVE as the media type.
4. Use the START TIME drop downs to choose the download starting time.
5. Use the DURATION drop down to choose the length of the download.
6. Insert USB drive into USB slot on front of unit.
7. Click START to begin video download.
8. Click CLOSE once the download is complete.
9. Move cursor to bottom of screen and click X to stop playback.
10. Click CLOSE to return to live video.

View Downloaded Video

1. Insert USB drive into USB slot on laptop or desktop computer.
2. Open the USB folder to view files.
3. Double click on DVR Player. Double click on HD Player.
4. The HD Player will be on the screen. Click on the Open Files In Folder icon in the lower right corner (second icon from left).
5. Find the USB drive which contains the file(s). Click on it to display the folders.
6. Find the folder (name of folder will be the date downloaded).
7. Click on folder to show the video file(s).
8. Highlight video file and click OK. Video will begin to play.
9. Double click any channel to make it full screen.
10. Use icons at bottom center to control playback.
11. Use icons at lower right for storage options or still image capture.