

## Communication Test Procedure

Push keypad **CMD** button until **MENU NO YES** appears on screen.

Push top row button under **YES**

**ENTER CODE**- will appear on screen.

Enter your user code on the keypad.

**SENSOR RESET?** will appear on screen.

Push the keypad **CMD** button until **SYSTEM TEST** appears on screen

Push any top row key to initiate the system test.

The siren will sound for 3 seconds, then the keypad for 3 seconds.

The back-up battery will test. A **BATTERY OK** message indicates good battery condition.

If **BATTERY LOW** or **BATTERY TRBL** appear on the screen, battery replacement is needed.

**TRANSMIT TEST** will appear on the screen while a test signal is sent to the monitoring center.

This will not cause an alarm signal to be sent, only a test signal.

If communication was successful, **TRANSMIT OK** will appear on the screen. The system will then return to normal operation.

If **TRANSMIT FAIL** appears, you should contact VEI Protective Services at 812-886-5790 to schedule a service call.